

OWNER'S MANUAL SUPPLEMENT

For lifts equipped with a single-speed or
two-speed hydraulic foot pump
MODEL 1-SPEED / 2-SPEED FOOT PUMP

Contents

Warnings and Safety Instructions.....	1	AirBleed Procedure.....	3
Receiving Instructions.....	1	Trouble Shooting Guide for Single and Two- Speed Hydraulic Foot Pump.....	4
Model Number & Capacity.....	1	Hydraulic Schematic.....	4
Parts Diagram for Single and Two Speed Hydraulic Foot Pump.....	2	Speed Selection for Two-Speed Hydraulic Foot Pump.....	4
Foot Pump Operating Instructions.....	2		
Parts Identification for Single and Two Speed Hydraulic Foot Pump.....	3		

WARNINGS & SAFETY INSTRUCTIONS

Read owner's manual completely before operating unit!

- * Remove weight before working on unit.
- * Use only maintenance parts supplied or approved by the manufacturer.
- * Do not change pressure relief valve setting.
- * Do not clamp pump in a vise as you may distort barrel.
- * Do not continue to pump if unit is not raising.
- * Relieve system pressure by slowly depressing lowering valve.
- * Do not use hydraulic oils, brake fluids or jack oils. Use AW-32 or equal.

RECEIVING INSTRUCTIONS


Every unit is thoroughly tested and inspected prior to shipment. However, it is possible that the unit may incur damage during transit. If you see damage when unloading make a note of it on the SHIPPER RECEIVER.

Remove all packing and strapping material and inspect unit for damage. IF DAMAGE IS EVIDENT, FILE A CLAIM WITH THE CARRIER IMMEDIATELY!

Also, check the unit size, type of power unit, etc., to see that the unit is correct for the intended application.


MODEL NUMBER AND CAPACITY

The model number and capacity is located on the nameplate. Please remember to include these numbers in any correspondence with your dealer or the factory.



(2-Speed Foot Pump Shown)

Parts Diagram for Single and Two-Speed Hydraulic Foot Pumps



Operating Instructions

Features:

Your new lift equipment has been supplied with an exclusive single-speed or two-speed foot pump. The internal features of your pump include a primary pressure relief, pressure compensated return flow control valve, and an integrated lowering valve. Replaceable bushings, valve components, and seals have been utilized in the construction of the pump in the event that replacements are necessary.

Operating Instructions:

Stay clear of moving parts. The platform will rise as the foot pedal is pumped. Depressing the release lever will lower the table at a controlled rate of descent.

In the event the platform has been overloaded, the pressure relief will open because of excessive pressure build-up in the hydraulic system. Oil will bypass into the reservoir. **Never** increase the pressure relief setting more than necessary. **Do not** exceed the rated capacity of your lift equipment.

Two-Speed Selection:

The two-speed hydraulic foot pump offers two "speeds". The low speed produces *low volume/high pressure*. The high speed produces *high volume/low pressure*. The operator has the option of selecting the optimum pump speed for the application at hand. Pump speeds are selected by sliding the "lock collar" (Item # 2 on the parts identification) in or out. An occasional drop of oil will keep the collar working freely.

Parts Identification for Single and Two-Speed Hydraulic Foot Pumps

ITEM NUMBER	DESCRIPTION	PART NUMBER	QUANTITY
1	Assembly, lever delta foot pedal, double speed	01-540-003	1
1A	Assembly, lever delta foot pedal, single speed	01-540-004	1
2	Linkage for single-speed foot pump	NFP-LNK1	1
2A	Linkage for two-speed foot pump	NFP-LNK2	1
3	3/8" x 1-3/4" dia. detent pin	01-130-004	1
3A	3/8" x 1-1/4" dia. detent pin	01-130-005	1
4	Pump plunger	01-041-004	1
<input type="checkbox"/> A 5	Piston wiper seal	550110	1
<input type="checkbox"/> A 6	Piston U-cup seal	532101	1
7	Piston return spring	01-146-004	1
8	1/4" x 1-1/2" spring pin	64251	1
9	3/8" x 1-3/4" dia. Driv-Loc pin	01-130-004	1
10	Sleeve sintered bronze bearing	01-111-038	3
11	Fitting, "O"-ring plug	01-116-007	1
12	Pressure compensated flow control valve	01-127-007	1
13	Release check spring	01-146-002	1
14	5/16" dia. steel ball	01-145-001	1
15	Pump body/manifold	NFP-BDYMAN	1
16	Fitting, "O"-ring plug	01-116-007	1
17	3/8" dia. chrome steel ball	01-145-003	1
18	Pressure relief spring	01-146-005	1
<input type="checkbox"/> A 19	Fitting, pressure adjustment plug	01-116-006	1
20	Fitting, "O"-ring plug	01-116-007	1
21	Release pin	01-112-016	1
<input type="checkbox"/> A 22	Release pin seal retaining ring	565011	1
<input type="checkbox"/> A 23	Release rod U-cup seal	01-144-002	1
24	Fitting, hydraulic plug	01-116-004	1
25	Release lever	01-040-001	1
26	Release lever retaining screw	01-119-001	1
27	3/16" x 1-1/8" spring pin	64134	1
28	5/16" dia. chrome steel ball	01-145-001	1
29	Inlet check spring	01-146-001	1
30	7/16" dia. chrome steel ball	01-145-004	1
31	Outlet check spring	01-146-001 01-146-001	1
32	Fitting, "O"-ring plug	01-116-007 -007	1
33	1/4" -20 x 1/4" socket head cap screw	562008	1
<input type="checkbox"/> A 34	1/4" sealing washer (copper with rolled core)	577004	1
<input type="checkbox"/> A	Foot Pump rebuild kit (includes items 5, 6, 19, 22, 23, & 34)	01-136-403	1

Kit item (included with purchase of kit)

Air Bleed Procedure

Whether your pump is a new installation, or has been recently serviced, air has likely entered the hydraulic system. The design of this pump includes an "air bleed screw" which will aid in the removal of unwanted air from the foot pump area of the hydraulic system. Use the following steps to remove this air from the system.


- 1) Check all fittings to be sure they are tight. Ensure that the oil is filled to within 1" of the top of the reservoir when the lift is in the fully lowered position.
- 2) Locate the "air bleed screw" (Item # 34 on the pump body) and loosen approximately 1/2 turn counterclockwise. As soon as you have loosened the screw, slowly depress the foot pedal. This will force the air out of the pump chamber. Before you let the pump pedal return to the "up" or "home" position, tighten the air bleed screw. This will prevent air from re-entering the pump chamber. Repeat the above procedure until the pump chamber is completely filled with oil and a "spongy" feel is no longer present. If the air bleeding procedure has been successful, the feel of the pump pedal will be firm and the complete stroke of the pump will produce fluid flow.

Air can also become trapped in the hydraulic cylinder(s). Review your owner's manual for air removal instructions.


Trouble shooting Guide for Single and Two-speed Hydraulic Foot Pump

Observation	Possible Cause	Remedy	<i>*Refer to exploded view</i>
1.) Deck does not raise	a. Excessive load b. Oil is low c. Pinched hose d. Relief valve set too low	a. Remove part of the load b. Fill oil to within one inch of the top of the reservoir c. Correct as necessary d. Increase only as necessary	
2.) Foot pedal goes down hard but deck does not raise	a. Particle of dirt under the pressure relief b. Particle of dirt under inlet check	a. Lower deck- Disassemble, clean and reassemble pressure relief* b. Lower deck- Disassemble, clean and reassemble inlet check valve*	
3.) Unit will pump under no load or when rapidly stroked, or pedal will stroke with out pumping	a. Pump is air locked b. Inlet check valve has foreign material on seat c. Relief setting is out of adjustment d. Foreign material on relief valve seat	a. Bleed air from system inlet b. Remove and clean inlet ball and seat c. Adjust relief setting higher d. Lowering valve has foreign material on the seat or is stuck in the open position	
4.) Platform raises when the pump is stroked but lowers on return stroke	a. Outlet check is leaking	a. Clean foreign material from ball and seat	
5.) Deck raises but takes too much effort	a. Change pump displacement speed	a. Slide locking collar back	
6.) Deck raises but is too slow	a. Change pump displacement speed b. Intake filter clogged c. Foreign material stuck under pressure relief valve or under inlet check valve	a. Slide locking collar forward b. Lower deck- drain reservoir, clean and flush debris, refill with clean oil c. Lower deck- Disassemble, clean and reassemble pressure relief*	
7.) Spongy or jerky operation	a. Check for foreign material stuck in the deck or frame rails b. Oil is low	a. Correct as necessary b. Fill oil to within one inch of the top of the reservoir	
8.) Deck lowers too slowly	a. Pinched hose b. Intake filter clogged c. Foreign material lodged in velocity fuse d. Foreign material lodged in pressure compensated flow control valve	a. Correct as necessary b. Correct as necessary c. Lower deck- Disassemble, clean and reassemble* d. Lower deck- Disassemble, clean and reassemble pressure relief*	
9.) Deck lowers too fast	a. Foreign material lodged in pressure compensated flow control valve	a. Lower deck- Disassemble, clean and reassemble pressure relief*	
10.) Deck raises but does not lower	a. Foreign material lodged in pressure compensated flow control valve b. Release pin bent or missing c. Foreign object blocking roller travel d. Velocity fuse is locked	a. Lower deck- Disassemble, clean and reassemble pressure relief* b. Replace as necessary c. Correct as necessary d. Remove air from hydraulic system, to un lock, repressurize system (refer to hydraulic section in manual)	

HYDRAULIC SCHEMATIC



Speed Selection for Two-Speed Hydraulic Foot Pump




SPECIFICATIONS:

- ___ 1 GPM PUMP
- ___ 3000 PSI MAXIMUM
- ___ 2.8 HP MODEL AIR MOTOR
- ___ LUBRICATION RATE: 10-12 DROPS PER MIN
- ___ MINIMUM AIR PRESSURE 80 PSI
- ___ MINIMUM 70 CFM (CUBIC FEET PER MINUTE)
- ___ MANUAL RAISE/LOWER CONTROLS
- ___ MINIMUM LINE SIZE 3/4" FOR THE LAST 50 FT. OF PIPE RUN

THE AIR SUPPLY MUST BE CLEAN AND RELATIVELY DRY. AN AIR LINE FILTER AND LUBRICATOR MUST BE FITTED IN THE AIR SUPPLY LINE AND LOCATED BEFORE THE FIRST CONTROL VALVE.

OPERATION OF THIS MACHINE WITHOUT A FILTER/LUBRICATOR WILL VOID THE WARRANTY

APPROVED BY: _____ DATE: _____



--- AIR LINE
 — HYDRAULIC LINES (SUPPLIED)

T & S EQUIPMENT COMPANY

ROTARY AIR/HYDRAULIC POWER UNIT
 WITH MANUAL CONTROL

DRAWN BY: B YEAKLE	SCALE: NONE	CHK'D:
DATE: 3/12/92		DRAWING NO:
APP'D:		AIRAPPRV