



Assembly instructions:

1. Insert threaded shaft of each castor through bolt holes in dolly frame (1).
2. Tighten a hex nut (3) onto the end of each castor.

3	36110	Hex Nut Z Plated, Ø 1/2 - 13	3
2	16-132-206	Ø3" X 1 1/4" CASTER	3
1	16-514-178	WELDMENT, FRAME	1
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.

Vestil Manufacturing Co.